

# Fuji D-6 Compression Plug Installation

- **Important!!! Do not remove the orange tube from fork!** This is needed for the front brake cable installation.
- Insert compression plug with orange tube through bolt. (see pic)



# Fuji D-6 Compression Plug Installation

- Pull orange tube from port on fork leg (top pic) just enough to allow the allen wrench to engage compression plug. (bottom pic)
- Be sure not to pull orange tube too far!!



# Fuji D-6 Compression Plug Installation

- After compression plug is tightened, push orange tube back to its original position.



# Fuji D-6 Compression Plug Installation

- Feed brake cable through top cap and adjust headset using a Park red pin spanner (**SPA-2**).

